

Quick Start Guide

Elevate Unified Communications
Polycom VVX 150



Welcome to Elevate Unified Communications

What's in the box?

Polycom VVX 150

A. Phone

B. Ethernet Cable


C. Handset Cable

D. Handset


E. Stand

F. Power Adapter


A.




B.




C.




D.



E.




F.



Guided Setup


Attach Stand

Attach the stand as shown below.




Connect Handset and Optional Headset

Note: Your phone supports wired headsets, including electronic hookswitch (EHS) headsets. For connection directions, refer to your headset documentation.




Note: Your phone supports wired headsets, including Electronic Hookswitch (EHS) headsets.

For connection directions, refer to your headset documentation. Standard headsets typically use the RJ-9 while EHS headsets use the RJ-9 and EHS ports.




Connect Cables

Please follow the diagram to install your phone. Once plugged in, the phone will automatically download its configuration and start to work. The voicemail box will be functional with a default greeting.




Features

Polycom VVX 150




Voicemail Box Setup

RECORDING YOUR PERSONAL VOICEMAIL GREETING

1. Press the "Home"  button.
2. Use the arrow keys to select "Msgs".
3. Press the Select soft-key on "Message Center"
4. Press the "Conn" soft-key to connect to voicemail.
5. Enter the PIN provided to you by your Administrator, followed by the # key.
6. Select option 3 for personal options.
7. Select option 1 to record your voicemail greeting.
8. Follow the voice prompts to record and check your greeting.

CHANGING THE PIN FROM THE PHONE

1. Press the "Home"  button.
2. Use the arrow keys to select "Msgs".
3. Press the Select soft-key on "Message Center"
4. Press the "Conn" soft-key to connect to voicemail.
5. Enter the PIN provided to you by your Administrator, followed by the # key.
6. Select option 3 for personal options.
7. Select option 2 to change your PIN.

Commonly Used Features

PLACING OUTGOING CALLS

When the phone is not in use:

1. Pick up the handset or press the "Speakerphone" button.
2. Dial an extension or telephone number.

When you are already on a call:

1. Press the "Hold" soft key.
2. Press the "Call" soft key.
3. Dial an extension or telephone number.
4. Resume the original call by pressing the "Line" button that corresponds with that call, and press the "Res" soft key.

ANSWERING AN INCOMING CALL

...On the Handset:

Pick up the handset to answer the call.

...On a Headset:

When a headset is connected, press the "Headset" button (or the "Answer" soft key) to answer the call.

...On Speakerphone:

Press the "Speaker" button (or the "Answer" soft key) to answer the call.

REJECTING AN INCOMING CALL

Press the "Reject" soft key to immediately send the caller to voicemail.

Note: Caller will continue to hear ringing after pressing "Reject" if you have multiple devices assigned to your User.

IGNORING AN INCOMING CALL

Press the "More" soft key followed by the "Ignore" soft key to send the caller to voicemail.

Note: The caller will continue to hear ringing for the specified amount of time, defined in the phone's "No Answer Forwarding" setting.

ENDING A CALL

On a Handset:

- Hang up the handset.

On a Headset:

- Press the "Headset" button.

On Speakerphone:

- Press the "Speakerphone" button.

HOLD

Placing a Call On Hold:

- While on a call, press the "Hold" soft key.

Retrieving Calls On Hold:

- Press the "Res" soft key.

MUTE

1. To mute the microphone on an active call, press the "Mute" button. "Microphone muted" will appear on the screen.
2. To un-mute the microphone, press the "Mute" button again. "Microphone unmuted" will appear on the screen.

TRANSFERRING CALLS

Blind Transfers:

1. While on a call, press the "Tsfr" soft key.
2. Dial the desired phone number or extension number.
3. Press the "Tsfr" soft key again.
4. The call is automatically transferred.

Attended (Consultative or Warm) Transfers:

1. While on a call, press the "Tsfr" soft key.
2. Dial the desired phone number or extension number.
3. Wait for the party to answer to announce that you are transferring a call to them.
4. Press the "Tsfr" soft key to transfer the call.

CALL WAITING

While already on a call, and a new call rings in, a Line Key on the phone will begin blinking green to indicate a new call is ringing in.

To Answer the Second Call:

1. Press the down arrow button to access the second call.
2. Press the "Ans" soft key to access that call. The first call will be placed on hold.
3. Once the second call has ended, resume the original call by pressing the "Res" soft key.

To Reject the Second Call:

1. Press the down arrow button to access the second call.
2. Press the "Reject" soft key to immediately send the caller to voicemail.

CALL WAITING (CONTINUED)

To Ignore the Second Call:

1. Press the down arrow button to access the second call.
2. Press the "More" soft key and press the "Ignore" soft key to send the caller to voicemail.

Note: The caller will continue to hear ringing for the specified amount of time, defined in the phone's "No Answer Forwarding" settings.

VOLUME ADJUSTMENT

In-Call Volume:

- While on a call, press the "+" and "-" buttons to raise or lower the volume.

Ringer Volume:

- While the phone is not in use, press the "+" or "-" buttons to adjust the ringer volume on the phone.

SPEAKERPHONE

While the phone is not in use:

- Press the "Speakerphone" button to activate the speakerphone and get dial tone for an outbound call.

While on a call on the handset or headset:

- Press the "Speakerphone" button to continue the current call on the speakerphone.

While a call on speakerphone is active:

- Press the "Speakerphone" button to hang up the current call.

FORWARDING CALLS


1. Press the "Fwd" soft key OR
2. Press the "Home" button and press the option corresponding to "Fwd".
3. If "Always Forward" is currently disabled, "Always (Disabled)" will be displayed.
4. Press 1 for "Always."
5. Enter / verify the contact number where calls will be forwarded.
6. Press the "Enable" soft key.

Disabling "Always Forward":

1. If "Always Forward" is currently enabled, "Always (Enabled)" will be displayed.
2. Press 1 for "Always."
3. Press the "Dsbl" soft key.

"Forward On Busy" and "Forward On No Answer" can be set in a similar manner.

VOICEMAIL

1. Press the "Home"  button.
2. Use the arrow keys to select "Msgs".
3. Press the Select soft-key on "Message Center"
4. Press the "Conn" soft-key to connect to voicemail.
5. Enter the PIN provided to you by your Administrator, followed by the # key.
6. Follow the voice prompts to listen to your messages.

We are here to help.



<http://cp.serverdata.net/KB/main/>